



JetWave 2211C
Industrial Dual 802.11n 2.4G/5G
2T2R MIMO Client

User Manual

V1.0 Oct, 2019

Copyright

Copyright © 2016 all rights reserved. No part of this publication may be reproduced, adapted, stored in a retrieval system, translated into any language, or transmitted in any form or by any means without the written permission of the supplier.

About This Manual

This user manual provides the following notes:

1. The Declaration of Conformity policy and manufacturer information.
2. The Safety Precaution and important notification.
3. The technical specification of the product.
4. The instruction on how to install and configure your product.

Please read this document carefully and only trained and qualified personnel should be allowed to install, replace, or service this equipment.

Conventions

For your attention on important parts, special characters and patterns are used in this manual:



Note:

This indicates an important note that you must pay attention to.

The Blue Wording is important note that you must pay attention to.

The Blue Wording with Big Case is very important note you must pay more attention to.



Warning:

This indicates a warning or caution that you have to abide.

The Red wording is very important you must avoid.

Bold: Indicates the function, important words, and so on.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

This device is restricted to indoor use.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Korenix Technology Co., Ltd.

14F., No.213, Beixin Rd., Xindian Dist., New Taipei City 23143, Taiwan (R.O.C.)

TEL: +886-2-8911-1000

Safety Precautions – JetWave Wireless Product

General Notification

- Only operate the device according to the technical specification. You can find the information from the product datasheet, user manual...etc.
- Read the installation instructions before connecting the system to the power source.
- If you don't get exact info you need, you can contact Korenix technical people, korecare@korenix.com. Only trained and qualified personnel should be allowed to install, replace, or service this equipment.

- The devices are designed for operation with extra-low voltage (SELV). Connect the unit only to DC power source that complies with the safety extra-low voltage (SELV) requirements in IEC/EN 60950 based safety standards.

(Not included 110V input model)

Solely connect the power supply that corresponds to the type of your device. For power connection, make sure the following requirement are met:

- The DC power circuit of the product is isolated design circuit. In practical, it is suggested to use isolated DC power design PSU for field installation. Besides the PSU selection, well digital/earth grounding is also important before power on the system.
- The Power Supply conforms to the overvoltage category I or II.
- The output voltage of the AC/DC to DC Power Supply conforms to the range of the input voltage of the equipment.
- The connection cables used are permitted for the specified electronic voltage, current, wire diameter and temperature range. (Wire Diameter of AC voltage is at least 0.75mm, AWG18. For DC voltage, it is at least 1.0mm, AWG16.)
- Follow the power installing instruction of the user manual, it indicates the input voltage, pin assignment, connection circuit and notice.
- The Power Supply must be well installed, includes grounded and other notices which are defined in its instruction guide.
- Only switch on the supply voltage to the device if the housing is closed, the terminal blocks are wired up correctly and the terminal blocks are connected.

- The equipment must be grounded. Ground the device before connecting the cables, antennas and power supply. The grounding of the equipment and DC Power Supply may be different in some applications, then, you must ground them separately.
- Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.

Environment & Housing

- **Hot surface.** Avoid touching the device while it is operating.
- Only operate the device at the specified ambient temperature and humidity. The temperature of the surrounding air means a distance of up to 5cm from the device. While installing multiple devices within the cabinet, remains suitable width between the devices is **MUST** for better heat dispersing.
- Better install the device in the vertical position, with the upper antenna connections pointing upward, lower antenna pointing downward.
- Install the device in a cabinet or in an operating site with limited access, the metal cabinet will filter the radio signals, use the extended antenna cable and install the external antenna in free space helps to get better Radio signal.
- Only technicians authorized by the manufacturer are permitted to open the housing. Without the manufacturer permitted, open the housing means the product is not warrantied and no responsible for any unexpected risk.

Installation

If you are installing the wireless equipment in the field box or outdoor area, for your safety as well as others', please seek assistance from a professional installer who has received safety training on the hazards involved. Keep safety as well as performance in mind when selecting your installation site, especially where there are electric power and phone lines.

Please note the following things as well:

- ◆ Do not use a metal ladder;
 - ◆ Do not work on a wet or windy day;
 - ◆ Wear shoes with rubber soles and heels, rubber gloves, long sleeved shirt or jacket.
-
- If you are installing the equipment in the indoor office or factory, be aware of the power source and grounding must be well installed. The professional Wireless IT Engineer can provide service for CLIENT location, channel and field plan to get better performance and coverage.
 - Connect the equipment which meets the IP degree of protection requirements for the application case.
-
- Read the Radio output power, receiver sensitivity, antenna gain specification before installing. The shipped products and antenna conforms to the R&TTE and allowed to be used in all European countries. You can read the related technical specification from the product datasheet or user manual.
 - When installing external antennas, the Radio Output power and antenna gain value must be allowed according to the regulations of the country.
 - When the system is operational with high gain antenna, avoid standing directly in front of it. Strong RF fields are present when the transmitter is on.
 - When the system is operational with high gain antenna in short distance, adjust the radio output lower. Strong output power plus high gain antenna is not good installation for short distance transmission.
-
- You are responsible for undertaking suitable lightning protection.
 - Install over voltage protector devices on every outdoor Ethernet cable.
 - Protect each antenna installed outside with lightning protection devices, ex: lightning arrester.

Note that Field EMD (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.

Content

Chapter 1 Introduction	10
1.1 Introduction	10
1.2 JetWave 2211C appearance	11
1.3 JetWave 2211C Major Features	11
1.4 JetWave 2211C Product Dimension	12
1.5 Product Package	12
Chapter 2 Hardware Installation	14
2.1 Professional Installation Required	14
2.1.1 Safety Precautions	14
2.2 Power Installation	16
2.2.1 DC Input	16
2.2.2 Connect both DC input	16
I/O Configuration	17
2.3.1 Wiring your Ethernet Port	17
2.3.2 Ground.....	18
2.3 WIFI Antenna	19
2.4.1 MIMO & Dual Polarization	19
2.4.2 Antenna Socket	20
2.4.3 Default External WIFI Antenna Specification:	21
2.4 Mounting	23
2.5.1 Din-Rail Mounting Installation.....	23
2.5.2 Mounting the SMA external antenna:	25
2.5 Using the External Antenna	26
Chapter 3 Prepare for Management	28
3.1 Basic Factory Default Settings	28
3.2 System Requirements	30
3.3 How to Login the Web-based Interface	30
3.4 Fail to login the Web GUI.....	31
3.5 Discovery Utility – Korenix View Utility	32

Chapter 4 Web GUI Configuration	34
4.1 Quick Setup	34
4.2 Status.....	35
4.2.1 Information.....	36
4.2.2 Network Flow.....	36
4.2.3 Bridge Table.....	37
4.2.4 ARP Table.....	38
4.2.5 DHCP Client List.....	38
4.2.6 Association List.....	39
4.3 System	41
4.3.1 Basic Settings.....	41
4.3.2 IP Settings	42
4.3.3 DHCP Server.....	42
4.3.4 RADIUS Settings	44
4.3.5 Time Settings.....	45
4.3.6 Relay Setting	45
4.3.7 WLAN Traffic shaping.....	46
4.3 Wireless	47
4.3.1 Basic Settings.....	47
4.3.2 Security Settings.....	51
4.3.3 Advanced Settings	53
4.3.4 Access Control	55
4.4 Management.....	56
4.4.1 Remote Setting.....	56
4.4.2 SMTP Configuration	58
4.4.3 Login Settings.....	58
4.4.4 Firmware Upgrade.....	59
4.4.5 Configuration File	60
4.4.6 Certificate File.....	61
4.4.7 Remote IP Scan	62
4.5 Tools	63
4.5.1 Save	63

4.5.2	Logout.....	63
4.5.3	Reboot.....	63
Chapter 5 Configuration – SNMP, CLI, View Utility.....		66
5.1	SNMP.....	66
5.1.1	What is SNMP?.....	66
5.1.2	Management Information Base (MIB):.....	67
5.1.3	MIB Tree in NMS.....	68
5.2	Command Line Interface (CLI).....	71
5.2.1	SHOW Command Set:.....	73
5.2.2	Set Command Set:.....	73
5.2.3	List Command Set:.....	74
5.2.4	Delete Command Set:.....	75
5.3	Korenix View Utility.....	77
5.3.1	Device Discovery:.....	77
5.3.2	Basic Tools Shortcut:.....	78
5.3.3	Wireless Panel.....	79
Chapter 6 Troubleshooting.....		82
6.1	General Question.....	82
6.1.1	How to know the MAC address of the CLIENT?.....	82
6.1.2	What if I would like to reset the unit to default settings?.....	82
6.1.3	Why can not access the Web-based management interface?.....	82
6.2	Wireless.....	83
6.2.1	What if the wireless connection is not stable after associating with an CLIENT under wireless client mode?.....	83
6.2.2	What if the wireless connection performance is not good, how to improve it?.....	83
6.3	Appendix.....	84
6.3.1	ASCII.....	84
Revision History.....		85



Chapter 1

Introduction

Chapter 1 Introduction

1.1 Introduction

The user manual is applied to Korenix JetWave 2211C Industrial Wireless Client. JetWave 2211C provide perfect solution to manage Ethernet/Wireless in flexible ways, such as TCP server, TCP client, UDP. JetWave 2211C creates a transparent gateway for the Ethernet communication to Wireless. The Wireless LAN solution is 802.11a/b/g/n with up to 300Mbps data rate. Give you an easy way and high bandwidth connection to the hard-to-wire devices, ease your network cabling problem in the field.

Model List

JetWave2211C-E: 1 x Fast Ethernet Ports EU version

JetWave2211C-U: 1 x Fast Ethernet Ports US version

1.2 JetWave 2211C Appearance




1.3 JetWave 2211C Major Features

Features:

- Industrial Slim Size Wireless CLIENT
- IEEE 802.11a/b/g/n 2.4G & 5G Wi-Fi, up to 2T2R MIMO, 300Mbps
- 1-port Fast Ethernet Port
- Management by Web GUI and Korenix View Commander
- Event Warning by Syslog, Email and SNMP trap
- Heavy Industrial Grade design
- Operating Temperature: -40~75°C
- Triple Power Inputs by 9~48VDC Terminal Block

1.4 JetWave 2211C Product Dimension



1.5 Product Package

The product package you have received should contain the following items.

Package

- JetWave 2211C unit
- 2 x Wi-Fi 2.4G+5Ghz Antenna
- Din-Rail Mounting Kit
- 6-pin terminal connector
- Quick Installation Guide

Note: Please download the utility and user manual from Korenix Web site.



Chapter 2

Hardware Installation

Chapter 2 Hardware Installation

This Chapter describes safety precautions and product information before installing JetWave 2211C.

2.1 Professional Installation Required

- Please seek assistance from a professional installer for field installation or professional IT Engineer for indoor installation. These engineers must be well trained in the RF installation and knowledgeable for the Wireless CLIENT setup and field plan.
- The JetWave 2211C series is distributed through distributors and system installers with professional technicians and will not be sold directly through retail stores.

2.1.1 Safety Precautions

To keep you safe and install the hardware properly, please refer to the safety precautions in the front pages of this manual. **The Safety Precautions described in the front pages include General Notification, Power Source & Grounding Notification, Environment & Housing Notification and Installation Notification.**

Additional Notification for the product:

1. The DC power circuit of the product is isolated design circuit. In practical, it is suggested to use isolated DC power design PSU for field installation. Besides the PSU selection, well digital/earth grounding is also important before power on the system. Connect the Ethernet Cables, Antennas or Antenna RF Cables, Ground and Power Terminal Block well before powering on.

2. If you are installing the product in the field box, for your safety as well as others', please seek assistance from a professional installer who has received safety training on the hazards involved. Keep safety as well as performance in mind when selecting your installation site, especially where there are electric power and phone lines. Please note the following things as well:

- Do not use a metal ladder
- Do not work on a wet or windy day
- Wear shoes with rubber soles and heels, rubber gloves, long sleeved shirt or jacket.


3. If you are installing the product in the indoor office or factory, be aware of the power source and grounding must be well installed. The professional Wireless IT Engineer can provide service for location, antenna and field plan to get better performance and coverage.

4. When you exchange to high gain antenna on JetWave 2211C, please notice that the Radio Output power and antenna gain value must be allowed according to the regulations of the country. And avoid standing directly in front of high gain antenna. Strong RF fields are present when the transmitter is on.

5. You are responsible for undertaking suitable lightning protection. Install over voltage protector devices on every outdoor Ethernet cable. Protect antennas installed outside with lightening protection devices, ex: lightening arrester.

Note that Field EMD (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.

6. The operating temperature of JetWave 2211C series is from -40 to 75°C, please MUST installed the device in a restricted access location to avoid the hot surface of housing, and make more aware of potential hazards and reduce the risk.



2.2 Power Installation

The system provides dual DC power input.

2.2.1 DC Input

1. There is one 6-pin terminal block within the package, which is applied for screwing the DC wires. It is a good practice to turn off the system power, and to unplug power terminal block before making wire connections
2. Insert the positive and negative wires into the V+ and V- contact on the terminal block connector. Tighten the wire-clamp screws to prevent DC wires from being loosened. The range of the suitable electric wire is from 12 to 24 AWG.
3. The typical and suggest power source is DC 24V, the acceptable range is range from 9~48V. The dual DC power can be redundant. You can connect one power to typical power source and the other to battery/UPS as backup.
4. If you connect the wrong positive/negative wires, the system would not be power on or cause unexpected error. Please avoid this in field installation.

2.2.2 Connect both DC input

The 2 power sources DC input are redundant power design. When you connect 2 power sources, for example you connect the DC Power 1. While you power on the DC power 1 as the 1st power source, the DC power 2 port will not power from DC power 2. In this condition, while the DC power source failure, the other power source can seamlessly redundant.

I/O Configuration

2.3.1 Wiring your Ethernet Port

There are one Fast Ethernet ports. The 1 port is standard RJ-45 form factor. It can support 10Base-TX and 100Base-TX. All the Ethernet ports will auto-detect the signal from connected devices to negotiate the link speed and duplex mode. Auto MDI/MDIX allows users to connect another switch, hub or workstation without changing straight through or crossover cables. In some cases, the MDI/MDI-X may requests the connected device support auto-negotiation.

Available Cable Type:

10Base-T: 2-pair UTP/STP Cat. 3, 4, 5 cable (100m)

100 Base-TX: 2/4-pair UTP/STP Cat. 5 cable (100m)

Cable Request in Harsh environment: CAT 5E/CAT 6 is preferred for Data transmission.


Wiring STP Cable: STP (Shielded Twisted Pair) cable is preferred. The device is a heavy Industrial EMC certificated product and usually install in harsh environment, part of the EMS protection are based on STP cable, for example the surge protection of front Ethernet ports. STP cable can provide better field protection. It is MUST for the device installation in harsh environment.

Reset

There is one reset button located on the top of the device. The reset button provides users with a quick and easy way to restore the default settings of JetWave 2211C. Press reset button for 7 seconds. JetWave 2211C unit will restore to default value including default IP address (192.168.10.1), and no password. When the Power LED turns green, the device is ready to function.

2.3.2 Ground

To ensure the system will not be damaged by noise or any electrical shock, we suggest you to make exact connection with the Earth Ground. There is one Earth Ground screw on the bottom side of the device. Loosen the earth ground screw then tighten the screw after earth ground wire is connected.



2.3 WIFI Antenna

The JetWave 2211C equips two antenna sockets for Wireless 2T2R MIMO. The product attaches the Wi-Fi antennas inside the package.

Model Name/ Type	JetWave 2211C
Radio	802.11n 2.4GHz/5G
Antenna (Wifi Dual Band)	2dBi for 2.4G 4dBi for 5G

2.4.1 MIMO & Dual Polarization

➤ What is MIMO:

With the rising data rates and signal congestion, the MIMO is the proposed radio technology in IEEE 802.11n and accepted popularly. MIMO is short of the Multiple-Input and Multiple-Output, is the use of multiple antennas at both the transmitter and receiver to increase the wireless communication bandwidth, for example the 2T2R means 2 Transmitter and 2 receiver, then the bandwidth is double than SISO. MIMO technology offers significant increases in data throughput without additional bandwidth or increased transmit radio power.

The below figure shows the SISO technology, each transmitter and receiver has single radio.



The below figure shows the MIMO technology, the transmitter and receiver spread the total transmit power to 2 (or more) different radio antenna for communication.

MIMO




➤ What is Polarization:

Polarization is a property of wireless antenna, the polarization determines the antennas that can pick up the signal, for example you can set up two antennas in close and pointing to the same direction, but with different polarization. The result is only antennas with the same polarization will be able to communicate with each other, this is important especially in point-to-point wireless communication.

There are two major polarizations, Vertical and Horizontal. The antenna may support either one, you can choose Vertical or Horizontal polarization for the antenna installation. The result would be that antenna which is vertically polarized would only receive the signal from the vertically transmitting antenna, horizontally polarized antenna would only receive horizontally transmitting antenna.

The below figures show the typical Horizontal / Vertical polarization:



2.4.2 Antenna Socket

The JetWave 2211C supports IEEE 802.11n and 802.11ac 2T2R MIMO technology. JetWave 2211C series is embedded antenna that you don't need to mount external antennas. JetWave 2211C is external antenna model, it equips SMA Type antenna sockets for two WIFI radio (2x sockets by option), you can connect 2 WIFI antennas based on your need.

Antenna terminal side

JetWave 2211C Antenna terminal side




2.4.3 Default External WIFI Antenna Specification:

The following information applied to the default WIFI antenna.


External SMA type 2.4G/5G 2T2R Antenna			
Frequency (MHz)	2400-2500	5150-5350	5475-5875
Peak gain(dBi)	2.44	4.41	4.73
VSWR	1.8 : 1 Max.		
Polarization	Linear, vertical		
Impedance	50 Ω		

Reference Distance: The suggested distance of the embedded WIFI antenna is from 150 to 300 meters wide in public space. (However, the free space lost may affect the transmitting distance, so that the device may have different performance in different environment.)


➤ **2.5G Antenna Radiation Pattern**



➤ **5.15G Antenna Radiation Pattern**



➤ **5.55G Antenna Radiation Pattern**



2.4 Mounting

2.5.1 Din-Rail Mounting Installation


The DIN-Rail clip is already attached to the JetWave 2211C when packaged. If the DIN-Rail clip is not screwed on the Switch, follow the instructions and the figure below to attach DIN-Rail clip to the Switch.

Use the screws to attach DIN-Rail clip to the rear panel of Switch.


1. Use the screws to attach DIN-Rail clip to the rear panel of Switch.
2. To remove DIN-Rail clip, reverse step 1.

Follow the steps below to mount the Ethernet Switch to the DIN-Rail track:

1. First, insert the upper end of DIN-Rail clip into the back of DIN-Rail track from its upper side.



2. Lightly push the bottom of DIN-Rail clip into the track.



3. Check if DIN-Rail clip is tightly attached on the track.

4. To remove it from the track, reverse the steps above.

Notes: The DIN Rail should compliance with DIN EN50022 standard. Using wrong DIN rail may cause system install unsafe.

2.5.2 Mounting the SMA external antenna:

While selecting the SMA external antenna, you must use SMA type, please notice that the antenna should support Vertical Polarization for 2T2R MIMO radio transmission.

2.5 Using the External Antenna

Consult your system integrator or our technical support engineer to choose the suitable external antenna with SMA-type for your application.

Select the External Antenna:

Gain: It affects the system performance.

Polarization: Vertical Polarization is MUST for this 2T2R MIMO product.

Connector: SMA-Type.

Note:

-
- When prepare the external antenna, make sure the antenna can support Vertical Polarization.
 - Most of high gain external antenna is installed in higher place than CLIENT, get low power lost antenna cable in advance.
 - While installing the CLIENT within metal field box, connect the extended antenna cable to outside the box is must to avoid the Radio lost.
-



Chapter 3

Prepare for Management

Chapter 3 Prepare for Management

The JetWave 2211C Series supports Web GUI Configuration, Simple Network Management Protocol (SNMP), Telnet and Diagnostic Command Line Interface for management and Window Utility helps you discover the device cross network, basic IP setting, firmware management...etc.

This Chapter describes the preparation for management. In your first time access the device, you can refer to the [Basic Factory Default Settings](#) to know the default settings and the default IP of the device.

The Chapter also tells you how to login the Web-based interface, Diagnostic Console. If you forget IP address you changed, you can use Korenix View Utility to discover the devices' IP address and then access it.

3.1 Basic Factory Default Settings

We elaborated the JetWave 2211C Series basic factory default settings. You can re-acquire these parameters by default. This info is easier for you to find the device and access the switch's configuration interface. For further info, please refer to configuration guide of the feature set.

Table 1 JetWave 2211C Basic Factory Default Settings

Features	Factory Default Settings
Username	admin
Password	admin
Model Name	JetWave2211C
Device Name	korenixXXXXXX (X represents the last 6 digits of Ethernet MAC address)
Country/Region	By model: JetWave2211C-E: European Union JetWave2211C-U: United States JetWave2211C: All Country

Default IP (Lan Settings)		
IP Address		192.168.10.1
Subnet Mask		255.255.255.0
Default Gateway		0.0.0.0
Default IP		
IP Setup	Access Type	Static IP
	IP Address	192.168.1.1
	Subnet Mask	255.255.255.0
	Default Gateway	0.0.0.0
	DNS1	8.8.8.8 (Google IP)
	DNS2	0.0.0.0
	(Refer to the System – IP Settings for further information)	
Wireless Settings		
Wireless Basic Setting	Wireless Mode	CLIENT
	Wireless Network Name (SSID)	JetWave_1 (WLAN 1)
	Broadcast SSID	Enabled
	802.11 Mode	802.11G/N
	Frequency/ Channel	2437MHz(6)
	Channel Mode	20 MHz
	Data Rate	Auto
	(Refer to the Wireless – WLAN – Basic Settings)	
Wireless Advanced Settings	A-MPDU aggregation	Enabled
	A-MSDU aggregation	Disabled
	Short GI	Disabled
	RTS Threshold	2347
	Fragment Threshold	2346
	Beacon Interval	100
	DTIM Interval	1
	Preamble Type	Auto
Client Roaming	Disabled	
Other Settings		
Remote Settings	Remote Management Privacy	Telnet, SNMP
	Server Port:	161

SNMP	Get Community	Public
	Set Community	Private
	Trap Destination	0.0.0.0
	Trap Community	Public
Korenix View Utility	Device Search, IP Assign, Basic Tool, Wireless Panel	Note: While using Korenix View Utility to search the device, please connect to the LAN.

 **Warning:**

It is Important to change all the default settings of the Wireless CLIENT, includes the User Name, Password, Default IP Address, Default SSID, SNMP Community Name and configure Wireless Security to secure your network.

3.2 System Requirements

Before configuration, please make sure your system meets the following requirements:

- A computer coupled with 10/100 Base-T(X) adapter;
- Configure the computer with a static IP address of 192.168.10.X (X cannot be 0, 1, nor 255), as the default IP address of JetWave 2211C Series is 192.168.10.1
- A Web browser on PC for configuration such as Microsoft Internet Explorer 6.0 or above, Google Chrome or Firefox.

Note: If you want to do throughput test, not just configure the switch, please notice that the throughput of the high performance and low performance CPU must be different.

3.3 How to Login the Web-based Interface

The system provides you with user-friendly Web-based management tool.

Open Web browser and enter the IP address (Default: **192.168.10.1**) into the address field. You will see the WELCOME page as below.



Your Industrial Computing & Networking Partner

Welcome to the JetWave2211C-E
Industrial Dual 802.11n 2.4G/5G 2T2R MIMO Wireless Client

Name

Password

Figure – Web GUI Login Page

Enter the name of Account (Default: **admin**) and password (Default: **admin**) respectively and click “**Login**” to login the main page of the device. As you can see, this management interface provides main options in the above, which are **Quick Setup** , **Overview**. (Note: Routing page appears when Network Mode set [Route ETH WAN](#))



Figure - Main Page

3.4 Fail to login the Web GUI


If you failed to login the web GUI, there are something you can do for troubleshooting.

1. Normally, you can access the device by using any kind of Window based Web browser, such as Microsoft Internet Explorer, Google Chrome, Firefox..., to configure and interrogate the product from anywhere on the network. If you failed access in either of the above Web browser, this might be the interoperability issue among your PC, OS version, Web browser and our product. You can try another Web browser as first self-aid, it usually works.
2. Please disable the firewall setting of your browser. The firewall setting may block the connection from your PC to the device. Note that after finished the setting, re-enable your firewall to protect your PC.
3. Check the IP Setting, your PC and managed device must be located within the same subnet.
4. Check the connected port, the default GT1 and GT2 equipped with different IP Address in Router mode.
5. The Web UI connection session of the device will be logged out automatically if you don't give any input after 30 seconds. After logged out, you should re-login and key in correct user name and password again.
6. Please contact Korenix engineer (Korecare@korenix.com) once you have problem for login.

3.5 Discovery Utility – Korenix View Utility

Korenix View is client architecture. Users use the client application to issue the operations and there is a server on the device to do these operations. The major difference between the Korenix View and other management tools, ex. Web, CLI, and SNMP, is that the Korenix View can configure several devices at the same time.

The PC with Korenix View Utility can discover the CLIENT cross the IP subnet. But, if you want to do further configuration, the PC must be located in the same subnet with your CLIENT. Change the IP address of your PC or change the IP address of the CLIENT.



- Please download the latest Korenix View Utility from Korenix Web Support page.
- The Chapter 5.3 introduces how to use Korenix View Utility.



Chapter 4


Web GUI Configuration

Chapter 4 Web GUI Configuration

This Chapter describes the Web GUI for Software Configuration.

4.1 Quick Setup

Quick Setup page can be design for simple use case. User can complete WIFI setting without study complete user manual. Follow three steps below then can finish simple WIFI setting.



Device Settings


Device Name :	<input type="text" value="korenix2211cd"/> (max. 15 characters and no spaces)
Network mode :	Bridge (only supports bridge mode)

LAN IP Address Assignment

<input type="radio"/> Use DHCP <input checked="" type="radio"/> Use Static IP Address	
IP Address:	<input type="text" value="192.168.10.1"/>
Subnet Mask :	<input type="text" value="255.255.255.0"/>
Gateway IP Address :	<input type="text" value="0.0.0.0"/>
DNS 1 :	<input type="text" value="8.8.8.8"/>
DNS 2 :	<input type="text" value="0.0.0.0"/>

DHCP Server Settings :


DHCP Server:	<input type="text" value="Disabled"/>
--------------	---------------------------------------



Wireless Settings

Wireless Mode:	<input type="text" value=""/>
Wireless Network Name(SSID):	<input type="text" value="JetWave_1"/>
WPA Passphrase (Network Key):	<input type="text" value=""/> (length 8~63)
802.11 Mode:	5GHz <input type="text" value=""/>
Frequency/Channel:	5180MHz (36) <input type="text" value=""/>
AP Roaming:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled

Note : If the network key is empty that means it uses **Open System** authentication.



Network Settings

Device Name :	korenix2211cd	LAN Access Type:	Static IP Address
Network mode :	Bridge	IP Address:	192.168.10.1
DHCP Server:	Disabled	Subnet Mask :	255.255.255.0
		Gateway IP Address :	0.0.0.0
		DNS 1 :	8.8.8.8
		DNS 2 :	0.0.0.0

Wireless Settings :


Wireless Mode:	AP
SSID:	JetWave_1
WPA Passphrase:	Empty (Open system)
802.11 Mode:	5GHz
Frequency/Channel:	5180MHz (36)
AP Roaming:	Disabled

4.2 Status

The Status feature set includes [Information](#), [Network Flow](#), [Bridge Table](#), [ARP Table](#) , [DHCP Client List](#) and [Association List](#). The information allows you to see the information of the device.

4.2.1 Information

This page shows the current status and some basic setting of the device.



System Information: The Model Name, Device Name, Country/Region you selected and Firmware version.

LAN Settings: It shows the IP Address, Subnet Mask and Default Getway of the MAC Address.

Wireless Settings: It shows the Operation Mode, Wireless Mode, SSID, Encryption, A, WMM State, Noise Floor.

Interface Status: This table shows the Interface Name, MAC Address, Status, Frequency and Rate.

4.2.2 Network Flow

This page shows the packet counters for transmission and reception regarding to Wireless 1, Ethernet.

Network Flow

Help

Poll Interval: (0-65534) sec

	Received	Transmitted
Wireless 1		
<i>Unicast Packets</i>	0	0
<i>Error Packets</i>	0	0
<i>Dropped Packets</i>	0	0
<i>Total Packets</i>	0	0
<i>Total Bytes</i>	0	0
LAN		
<i>Total Packets</i>	986	627
<i>Total Bytes</i>	146241	612888

Poll Interval: The poll interval time setting, range from 0~65534 seconds. If you want to change the poll interval time, press “Stop” and then enter new value, press “Set Interval” to activate.

Set Interval: Set new Interval time after enter new poll interval time.

Stop: Stop polling the associated aps.

4.2.3 Bridge Table

The table shows the Bridge table.

Bridge Table

Help

MAC Address	Interface	Ageing Timer(s)
40:b0:34:50:bc:9d	br0	0.00

Refresh

MAC Address: The MAC Address of the connected device.

Interface: The field shows the interface which learnt the MAC Address.

Ageing Timers(s): The aging time of the this entry. If the MAC didn't transmit any packet, the aging time will start counting, and delete the entry after aging timeout.

Refresh: Refresh the table.

4.2.4 ARP Table

This table shows the ARP table.

ARP Table

Help

IP Address	MAC Address	Interface
192.168.10.100	40:b0:34:50:bc:9d	br0

Refresh

IP Address: The IP Address learnt from the interface.

MAC Address: The MAC Address learnt from the interface.

Interface: The interface which learnt the ARP packet (IP and MAC Address).

Refresh: Refresh the table.

4.2.5 DHCP Client List

This table shows the assigned IP address, MAC address and Time Expired of the connected DHCP client devices.

DHCP Client List

Help

IP Address	MAC Address	Time Expired(s)
None	---	---

Refresh

IP Address: The assigned IP address of the connected DHCP client device.

MAC Address: The MAC Address of the connected DHCP client device.

Time Expired(s): The DHCP expire timer connected DHCP client device. Time unit is second. The number can be changed in DHCP Server Lease Time setting.

Refresh: Refresh the table.

4.2.6 Association List

This table shows the MAC Address, IP Address, RSSI and Connection Time for each associated devices.

Association List

Help

Poll Interval: (0-65534) sec

SSID	MAC Address	Signal Strength	Noise Floor	Connection Time	Last IP	Action
---	---	---	---	---	---	---

Refresh

Poll Interval: The poll interval time setting, range from 0~65534 seconds. If you want to change the poll interval time, press “Stop” and then enter new value, press “Set Interval” to activate new setting.

Set Interval: Set new Interval time after enter new poll interval time.

Stop: Stop polling the associated clients.

====Entry Info=====

SSID: The SSID of wireless interface that associated with wireless client device.

MAC Address: The MAC Address of the associated device.

Signal Strength: The signal strength of the associated device. The value can help you to see the connection quality of CLIENT/WDS-CLIENT.

Noise Floor: The Noise Floor of the associated device.

Connection Time: The time when the device connected to the CLIENT.

Last IP: The last IP address it had.


Action – Kick: This command allows you force kick the associated ap.

Refresh: The item helps you refresh the table manually.

4.3 System

For users who use the JetWave 2211C for the first time, it is recommended that you begin configuration from the “**System**” feature set pages shown below:

In System pages, there are some configuration pages for the system settings. These setups include Basic Settings, IP Settings, RADIUS Settings, Time Settings, Relay Settings and WLAN Traffic Shaping, these features are introduced in below pages.



4.3.1 Basic Settings

Use this page to configure the basic parameters of the device.

Device Name: User could give a name for identifying a particular Client here. It allows maximum 15 characters and no spaces.

Country/Region: Select the country you are installed. The channel number may be different based on your country.

Ethernet 1 Data Rate: Configure the Speed/Duplex of the WAN port. The default value, Auto means Auto-Negotiation. Force speed/duplex is available to setup here.

802.1Q VLAN: Enable or Disable 802.1Q VLAN. With 802.1Q enabled, the packet will attach the 1Q VLAN tag inside. To assign the VLAN ID for each CLIENT profile, you should enable 802.1Q VLAN first. Here is the global VLAN Enable setup.

Management VLAN ID: This is the management VLAN ID of the device. Only the client within the same management VLAN can access the device’s management interface. To enable Management VLAN ID, you must enable “802.1Q VLAN” and assign “VLAN ID” for each CLIENT profile first.

4.3.2 IP Settings

Use this page to configure the IP related parameters for LAN interfaces. Here you may change the setting for IP address, subnet mask, Gateway IP Address, DNS.

IP Settings

Help

LAN IP Address Assignment

<input type="radio"/> Use DHCP <input checked="" type="radio"/> Use Static IP Address	
IP Address :	192.168.10.1
Subnet Mask :	255.255.255.0
Default Gateway :	0.0.0.0
DNS 1 :	8.8.8.8
DNS 2 :	0.0.0.0

Use DHCP: User could give domain name system for the device.

Use Static IP address: .

IP Address: The IP Address field allows you to set the device's IP address manually.

Subnet Mask: You can change the subnet mask address for the LAN interface. The default subnet mask is a Class C address: 255.255.255.0

Gateway IP Address: This is the system gateway IP address.

DNS: The DNS (Domain name system) servers for this device. DNS is a hierarchical naming system built on a distributed database for computers, services, or any resource connected to the Internet or a private network. It associates various information with domain names assigned to each of the participating entities. Most importantly, it translates domain names meaningful into the numerical identifiers associated with networking equipment for the purpose of locating and addressing these devices worldwide

4.3.3 DHCP Server

Use this page to configure the **DHCP** Server Setting.

DHCP Server

Help

DHCP Settings:	Disabled ▼
DHCP IP Address Range Start :	192.168.10.100
DHCP IP Address Range End :	192.168.10.200
DHCP Subnet Mask:	255.255.255.0
DHCP Gateway:	192.168.10.1
WINS1 :	0.0.0.0
WINS2 :	0.0.0.0
Primary DNS Server :	8.8.8.8
Secondary DNS Server :	0.0.0.0
Lease Time(15-44640 Minutes) :	1440

Apply Cancel

Static MAC/IP Binding List

IP Address:	0.0.0.0
MAC Address:	

Add

IP Address	MAC Address	Select	Edit
------------	-------------	--------	------

Delete Selected Delete All Refresh

DHCP Settings: Enable / Disable the local DHCP Server. After the DHCP Server option is enabled, you can then assign the starting and ending IP of the DHCP IP address range. The device allows you to assign up to one Class C range which is 255 IP addresses. The maximum connections per session is 64.

DHCP IP Address Range Start: The starting address of the IP lease block.

DHCP IP Address Range End: The ending address of the IP lease block.

DHCP Subnet Mask: The subnet mask of the network.

DHCP Gateway: The default gateway IP address that you want the DHCP server to distribute.

WINS: The WINS server (NetBIOS name server) address that you want the DHCP server to distribute.

Primary/Secondary DNS Server: The DNS server address that you want the DHCP server to distribute.

Lease Time: The time in minutes a DHCP lease is valid for.

Press “**Apply**” to activate the settings.

4.3.4 RADIUS Settings

Use this page to configure the **RADIUS** Server Setting.

RADIUS (Remote Authentication Dial-In User Service) is a server for remote user authentication and accounting; it plays a central role in the network in providing the capabilities of authenticating, authorizing, accounting, alarming and etc. It allows an organization to maintain user profiles in a central database that all remote servers can share.

RADIUS Settings

Help

Authentication RADIUS Server

IP Address:	0.0.0.0
Port:	1812
Shared Secret:	

Global-Key Update

Key renewal:	every 3600	Seconds
--------------	------------	---------

Apply

Cancel

Authentication RADIUS Server

IP Address: Enter the IP address of the Radius Server;

Port: Enter the TCP port number of the Radius Server; the default port number is 1812.

Shared Secret: This secret, which is composed of no more than 31 characters, is shared by the device and RADIUS server during authentication.

Global-Key Update: Check this option and specify the time interval between two global-key updates.

Key renewal: Set the time interval between two authentications.

For User Security, please go to Wireless Security Setting page (Refer to the Chapter 4.4.2)

4.3.5 Time Settings

Use this page to configure the **Time Settings**. You can configure current time, time zone and configure NTP protocol to synchronize system time with a public time server over the internet.

Time Settings

Help

Current Time:	Yr <input type="text" value="2019"/> Mon <input type="text" value="11"/> Day <input type="text" value="30"/> Hr <input type="text" value="21"/> Min <input type="text" value="48"/> Sec <input type="text" value="11"/>
	<input type="button" value="Get PC Time"/>
Time Zone :	<input type="text" value="(GMT)Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London"/> ▼
NTP:	<input type="checkbox"/> Enable NTP client update
<input type="radio"/> NTP server:	<input type="text" value="pool.ntp.org - Global"/> ▼
<input checked="" type="radio"/> Manual IP:	<input type="text" value="0.0.0.0"/>

Apply

Refresh

Current Time: You can manually type the current time or get the time from you PC. Click “**Get PC time**”, the current time will be updated according to your PC’s time.

Time Zone Select: Select the time zone of your country from the dropdown list.

NTP: You can select “**Enable NTP client update**” in this page, then the NTP feature will be activated and synchronize from the remote time server.

NTP Server: Select the time server from the “**NTP Server**” dropdown list or manually input the IP address of available time server into “**Manual IP**”.

Press “**Apply**” to activate the settings.

4.3.6 Relay Setting

Use this page to configure the Link Failure Relay

Link Failure: You can Select the port number for which you want to monitor the link status. If a

link failure occurs on the selected ports, the system relay is triggered

Press “Apply” to activate the settings.

Relay Settings

Help

Link Failure :	Port <input type="checkbox"/> 1 WLAN <input type="checkbox"/> 1
----------------	---

Apply

Cancel

4.3.7 WLAN Traffic shaping

Use this page to specify the IP based Downstream and Upstream traffic limit.

Note: Only class B,C network address support

WLAN Subnet Traffic Shaping

Help

Enable Subnet Traffic Shaping

Downstream Limit (Eth->WLAN):	1000	Kbit/s
Upstream Limit (WLAN->ETH):	1000	Kbit/s
IP Address Range Start :	0.0.0.0	
IP Address Range End :	0.0.0.0	

Apply

Cancel

Enable traffic shaping: Use this check box to enable or disable traffic shaping

Downstream Limit: Maximum Downstream rate guaranteed. The range is 1000 to 1024000.

Upstream limit: Maximum Upstream rate guaranteed. The range is 1000 to 1024000.

IP address Range start: The begin IP address to limit.

IP address Range End: The end IP address to limit

Press “Apply” to activate the settings.


4.3 Wireless

The “**Wireless**” feature set pages allow users to configure the Wireless LAN configuration. The Wireless means the WIFI radio of the device. JetWave 2211C equip one-radio interface and it includes Basic Settings, Security Settings, Advanced Settings and Access Control can be configured in the WLAN Settings.

4.3.1 Basic Settings

Use this page to configure the parameters for Wireless LAN Interface of the device. Here you may change wireless interface modes and related parameters.

➤ WLAN 1- Factory default setting



Disable Wireless LAN Interface: Check this option to disable WLAN interface, then the wireless module of the CLIENT will stop working and no wireless device can connect to it.

Wireless Mode: The below operating modes are available on JetWave 2211C series.

JSM CLIENT: In JSM-Client mode, the JSM-Client will connect a Best signal JSM-AP and sync configuration with same band automatically. When JSM-AP config changed, the JSM client will change configuration at same time.

Wireless Client: The AP/Gateway is able to connect to the AP and thus join the wireless network around it. In Wireless Client mode, you can click "Site Survey" to find the best signal connected AP per your need. Or you can manually type the SSID you want to connect.

WDS-CLIENT: Select the WDS-Client mode. In WDS-Client mode, you must type the target WDS-AP's SSID and MAC address. With the setting, the traffic from the WDS-Client can Only

transmit to the WDS-AP. Please note that the rest of other wireless/security settings must be the same as the WDS-AP as well.

Wireless Network Name (SSID): This wireless network name is shared among all associated devices in your wireless network. Keep it identical on all those devices. Note that the SSID is case-sensitive and can not exceed 32 characters

Factory default SSID on WLAN 1: JetWave_1

Broadcast SSID: Enable or disable Broadcast SSID. Under CLIENT mode, hiding network name is necessary when you are in a wireless environment that may have potential risk. By disabling broadcast SSID, the clients can not scan and find the CLIENT, so that malicious attack by some illegal clients could be avoided.

802.11 Mode: The CLIENT can communicate with wireless devices of 802.11a/b/g/n. You can select 802.11 Mode and it will work under an appropriate wireless mode automatically. [WLAN 1 support 2.4G band, and 5G band.](#) Different band has different settings.

802.11 Supported Mode
WLAN 1
802.11A Only
802.11B Only
802.11G Only
802.11 G/N
802.11 A/N

HT Protect: Enable HT (High Throughput) Protect to ensure HT transmission with MAC mechanism. Under 802.11n mode, wireless client can be divided into HT STA and Non-HT STA, among which the one with HT protect enabled gets higher throughput.

Frequency/Channel: Channel varies much as the available band differs from country to country. Select a proper operating channel in the drop-down list according to your situation. By Our design, FCC support channel1~11,and CE support channel1~13 in 2.4G. In 5G, FCC support band1 and band4,and CE support only band1. And user will can choice the country code- All Country to open channel 1~13 in 2.4G,and band1~band4 channel in 5G.

Country/Region :

2.4G	5G
-------------	-----------

2437MHz (6) ▾ Auto 2412MHz (1) 2417MHz (2) 2422MHz (3) 2427MHz (4) 2432MHz (5) 2437MHz (6) 2442MHz (7) 2447MHz (8) 2452MHz (9) 2457MHz (10) 2462MHz (11) 2467MHz (12) 2472MHz (13)	5180MHz (36) 5200MHz (40) 5220MHz (44) 5240MHz (48) 5260MHz (52) 5280MHz (56) 5300MHz (60) 5320MHz (64) 5500MHz (100) 5520MHz (104) 5540MHz (108) 5560MHz (112) 5580MHz (116) 5600MHz (120) 5620MHz (124) 5640MHz (128) 5660MHz (132)	5680MHz (136) 5700MHz (140) 5745MHz (149) 5765MHz (153) 5785MHz (157) 5805MHz (161) 5825MHz (165)
---	---	---

Channel Mode: Two levels are available: 20MHz and 20/40MHz. The latter one can enhance the data rate more effectively, but takes more bandwidth, thus cause potential interference.


WLAN 1	
802.11G/N	802.11A/N
20 MHz ▾ 20 MHz 20/40 MHz 40 MHz	20 MHz ▾ 20 MHz 20/40 MHz 40 MHz

Maximum Output Power: Specify the signal transmission power. The higher the output power is, the wider the signal can cover, but the power consumption will be greater accordingly. Usually “Full” with proper antenna is preferred. **Half:** 1/2 of Full (Full -3dBm), **Quarter:** 1/4 of Full (Full -6dBm), **Eighth:** 1/8 of Full (Full -9dBm).


Full ▾ Lowest Eighth Quarter Half Full
--

Date Rate: Usually “Auto” is preferred. Under this rate, the CLIENT will automatically select the highest available rate to transmit. In some cases, however, like where there is no great demand for speed, you can have a relatively-low transmit rate for compromise of a long distance.

802.11G/N, 802.11A/N	802.11B Only	802.11G Only, 802.11A Only
	Auto ▾ Auto 1M 2M 5.5M 11M	Auto ▾ Auto 6M 9M 12M 18M 24M 36M 48M 54M



Extension Channel Protection: This is to avoid conflict with other wireless network and boost the ability of your device to catch all 802.11g transmissions. However, it may decrease wireless network performance. Compared to **CTS to Self**, the transmission amount of **RTS-CTS** is much lower. Press “**Apply**” to activate the settings.



4.3.2 Security Settings

The page allows you configure the Security Settings

Station Profile Settings

Help

Basic Settings

Profile Name:	Profile1
Wireless Network Name (SSID):	JetWave_1
WMM Support:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled

Security Settings

Network Authentication:	Open System ▼
Data Encryption:	None ▼
Key Type:	Hex ▼
Default Tx Key:	Key 1 ▼
WEP Passphrase:	<input type="text"/> Generate Keys
Encryption Key 1:	<input type="text"/>
Encryption Key 2:	<input type="text"/>
Encryption Key 3:	<input type="text"/>
Encryption Key 4:	<input type="text"/>

Back Apply Cancel

➤ Basic Settings

Profile Name: The profile name of the settings.

Wireless Network Name(SSID): This is the same SSID of the CLIENT.

Broadcast SSID: Normally, the SSID is broadcast and all the clients can search the SSID. For security concern, you can disable the Broadcast SSID function, then the clients can't search it and the client must type the correct CLIENT's SSID to connect the CLIENT. This is a simple security setting.

Wireless Separation: Wireless separation is an ideal way to enhance the security of network transmission. Under the CLIENT mode, enable "Wireless Separation" can prevent the communication among associated wireless clients.

WMM Support: WMM (Wi-Fi Multimedia) is a subset of 802.11e. It allows wireless communication to define a priority limit on the basis of data type, thus those time-sensitive data, like video/audio data, may own a higher priority than common one. In CLIENT mode, you will have more settings as below.

Max. Station Num: In Wireless CLIENT mode, you can define the maximum amount of wireless clients allowed to be connected. The maximum client of the system is 64. The most user access at the same time may cause system busy and the performance becomes lower. It is suggested to assign the value depends on how much bandwidth your client generally need, and totally bandwidth suggest is under 250Mbps for TCP based data transmission.

➤ **Security Settings**

Network Authentication: Select Network Authentication type.

Open System: It allows any device to join the network without performing any security check.

Shared Key: Data encryption and key are required for wireless authentication.

WPA with RADIUS: With warrant (username, password and etc.) offered by user, this kind of authentication can be realized with specific RADIUS server. This is the common way to be adopted in large enterprise network.

WPA2 with RADIUS: As a new version of WPA, only all the clients support WPA2, can it be available. If it is selected, AES encryption and RADIUS server is required.

WPA & WPA2 with RADIUS: If it is selected, AES & TKIP encryption and RADIUS server is required.


WPA-PSK: It is a simplified WPA mode with no need for specific authentication server. In this so-called WPA Pre-Shared Key, all you have to do is just pre-enter a key in each WLAN node and this is the common way to be adopted in large and middle enterprise as well as residential network.

WPA2-PSK: As a new version of WPA, only all the clients support WPA2, can it be available. If it is selected, the data encryption can only be AES and the passphrase is required.

WPA-PSK & WPA2-PSK: If it is selected, the data encryption will be AES & TKIP and the passphrase is required.

Data Encryption: If data encryption is enabled, the key is required and only sharing the same key with other wireless devices can the communication be established.

None: Available only when the authentication type is open system.



64 bits WEP: It is made up of 10 hexadecimal numbers.

128 bits WEP: It is made up of 26 hexadecimal numbers.

TKIP: Temporal Key Integrity Protocol, which is a kind of dynamic encryption, is co-used with WPA-PSK

AES: Advanced Encryption Standard, it is usually co-used with WPA2-PSK.

EAP Type: For WPA/WPA2 with Radius. The system supports **TTLS**, **LEAP**, **TLS**, **PEAP** and **FAST EAP** types. Select the EAP type and type the User Name, Password for the WAP/WPA2 with Radius.

Group Key update Period: Time interval for rekeying GTK (Broadcast/multicast encryption keys) in seconds. This defaults to 86400 seconds (once per day) when using CCMP/GCMP as the group cipher and 0 seconds means no update

Press “**Apply**” to activate the settings, and you can also press “**Back**” to check the **VAP Profile Settings** for each Profile.

 **Note:**

-
- (1) We strongly recommend you enable wireless security on your network!
 - (2) Only setting the same Authentication, Data Encryption and Key in the JetWave and other associated wireless devices, can the communication be established!
-

4.3.3 Advanced Settings

The page allows you to configure advanced wireless setting. These settings are only for more technically advanced users who have a sufficient knowledge about wireless LAN. **Some of these settings should not be changed unless you know what effect the changes will take. And some of the modification on them may negatively impact the performance of your wireless network.**

Wireless Advanced Settings

Help

A-MPDU aggregation:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
A-MSDU aggregation:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Short GI:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
RTS Threshold:	<input type="text" value="2347"/> (1-2347)
Fragment Threshold:	<input type="text" value="2346"/> (256-2346)
Preamble Type:	<input type="radio"/> Long <input checked="" type="radio"/> Auto
Space In Meter:	<input type="text" value="0-1500m"/> ▼
Ping Watchdog:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Mac Clone:	<input type="radio"/> Static <input type="radio"/> Auto <input checked="" type="radio"/> Disabled
Roaming:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled

Apply

Cancel

A-MPDU/A-MSDU Aggregation: Under CLIENT mode, the data rate of your CLIENT could be enhanced greatly with this option enabled; however, if your wireless clients don't support A-MPDU/A-MSDU aggregation, it is recommended not to enable it.

Short GI: Under 802.11n mode, enable it (Short Guard Interval) to obtain better data rate if there is no negative compatibility issue.

Short GI: Under 802.11n mode, enable it (Short Guard Interval) to obtain better data rate if there is no negative compatibility issue.

RTS Threshold: The CLIENT/Gateway sends RTS (Request to Send) frames to certain receiving station and negotiates the sending of a data frame. After receiving an RTS, that STA responds with a CTS (Clear to Send) frame to acknowledge the right to start transmission. The setting range is 0 to 2347 in byte. The default value is 2347.

Fragment Threshold: Specify the maximum size in byte for a packet before data is fragmented into multiple packets. Setting it too low may result in poor network performance. Leave it at its default of 2346 is recommended.

Beacon Interval: Specify the frequency interval to broadcast packets. Enter a value between 20 and 1024. The default value is 100ms.

DTIM Interval: DTIM, which stands for Delivery Traffic Indication Message, is contained in the data packets. It is for enhancing the wireless transmission efficiency. The default is set to 1. Enter

a value between 1 and 255.

Preamble Type: It defines some details on the 802.11 physical layer. “Long” and “Auto” are available.

Roaming: Under Client mode, STA will roaming to better CLIENT if the RSSI of client is lower than setting of Roaming Threshold.

4.3.4 Access Control

This page allows you configure the Wireless Access Control list. You can configure Allow list or Deny list for your wireless network on the JetWave2211C.

The screenshot shows the configuration interface for Wireless Access Control. It features a title bar with 'Wireless Access Control' and a 'Help' button. The main configuration area includes a dropdown menu for 'Access Control Mode' (currently set to 'Disable') and a text input field for 'MAC Address'. Below these are 'Apply' and 'Cancel' buttons. A table header is visible with columns for 'MAC Address', 'Select', and 'Edit'. At the bottom of the interface are three buttons: 'Delete Selected', 'Delete All', and 'Refresh'.

Access Control Mode: Allow Listed or Deny Listed.

MAC Address: Type the MAC address of the client which you want to Allow or Deny.

Press “Apply” to activate the new settings.

The lower screen shows the Wireless Access Control list you configured. Press “Delete Selected” or “Delete All” to delete part of or all of the entries. Press “Refresh” to refresh the table.

4.4 Management

The “**Management**” feature set pages allow users to configure the Remote Setting, SMTP Configuration, Login Settings, Firmware Update, Configuration File, Certification File, Controller, Remote IP Scan and Topology Discovery.

4.4.1 Remote Setting

Use this page to set the Remote Management Privacy with selected Event Warning Type.

And this page also includes the configuration of SNMP settings V2c and V3.

Please make sure the configuration of SNMP should match between the device and SNMP server.

- JetWave2211C-E
- ├── Status
- ├── System
- ├── Wireless
- ├── Management
 - Remote Settings
 - SMTP Settings
 - Login Settings
 - Firmware Upgrade
 - Configuration File
 - Remote IP Scan
- ├── Tools
 - Save
 - Logout
 - Reboot

Remote Settings Help

Remote Management Privacy

Telnet

SNMP

SNMP Trap

SSH

Force HTTPS

Email Alert

Event Warning Type

Wlan Association

Authentication Fail

Config Changed

SNMP Settings

Protocol Version:	V2c ▼
Server Port:	161
Get Community:	public
Set Community:	private
Trap Destination:	0.0.0.0
Trap Community:	public

Configure SNMPv3 User Profile

Apply
Cancel

➤ Remote Settings

Remote Management Privacy: You can select which kinds of remote service should be opened in your environment. The services include **Telnet**, **SNMP**, **SNMP Trap**, **SSH**, **Force HTTPS** and **Email Alert**. Select the service and press “**Apply**” to activate the settings.

Event Warning Type: The event warning type selection.

Wlan Association: The client associated to the CLIENT event.

Authentication Fail: The client failure of authentication event.

Config Changed: The configuration of the CLIENT/Gateway is changed event.

➤ **SNMP Settings**

SMTP Settings

Help

SMTP Server IP:	<input type="text"/>
Email Account:	<input type="text"/>
Authentication Protocol:	None ▼
User Name:	<input type="text"/>
Password:	<input type="password"/>
Confirm Password:	<input type="password"/>
Rcpt Email Address 1:	<input type="text"/>
Rcpt Email Address 2:	<input type="text"/>

Apply

Cancel

Protocol Version: Select the SNMP version, and keep it identical on the device and the SNMP manager. While you chose SNMPv3 and applied, you must configure the SNMPv3 User Name, Password and their Access type, Authentication and Privacy Protocol in below SNMPv3 User Profile.

Server Port: Change the server port for a service if needed; however you have to use the same port to use that service for remote management.

Get Community: Specify the password for the incoming Get and GetNext requests from the management station. By default, it is set to public and allows all requests.

Set Community: Specify the password for the incoming Set requests from the management station. By default, it is set to private.

Trap Destination: Specify the IP address of the station to send the SNMP trap to.

Trap Community: Specify the password sent with each trap to the manager. By default, it is set to public and allows all requests.

 **Note:**

For security concern, it is recommended change the Community Name before you

connect the CLIENT to the network. The experience engineer who familiar with SNMP protocol can easily discovery and change the configuration of the CLIENT/Gateway through SNMP once you use the default communication name.

4.4.2 SMTP Configuration

The CLIENT supports E-mail Warning feature. The CLIENT will send the occurred events to remote E-mail server. The receiver can then receive notification by E-mail. The E-mail warning is conformed to SMTP standard. This page allows you to enable E-mail Alert, assign the SMTP Server IP, Sender E-mail, and Receiver E-mail. If SMTP server requests you to authorize first, you can also set up the username and password in this page.

SMTP Server IP: The IP Address of the SMTP server.

E-mail Account: The Sender's Email Account.

Authentication Protocol: If the SMTP server requires authentication, select the Authentication Protocol and enter User Name and Password.

User Name: The User Name of the sender E-mail account.

Password: The password of the Sender e-mail account.

Rcpt Email Address: The Receiver's e-mail address.

Press “**Apply**” to activate the change.

4.4.3 Login Settings

Use this page to set the user name and password of the CLIENT. Type the **User Name**, **New Password** and **Confirm Password** again.

Press “**Apply**” to activate the new password.

Login Settings

User Name:	<input type="text" value="admin"/>
New Password:	<input type="text"/>
Confirm Password:	<input type="text"/>

4.4.4 Firmware Upgrade

In this section, you can update the latest firmware for your CLIENT. Korenix provides the latest firmware in Korenix Web site. The new firmware may include new features, bug fixes or other software changes. We'll also provide the release notes for the update as well. From technical viewpoint, we suggest you use the latest firmware before installing the CLIENT to the customer site.

Note: The system will be automatically rebooted after you finished upgrading new firmware. Please remind the attached users before you do this.

Firmware Upgrade

Help

Local file

Select File:	選擇檔案 未選擇任何檔案
<input type="button" value="Upgrade"/> <input type="button" value="Cancel"/>	

TFTP

IP	<input type="text"/>
File Name	<input type="text"/>
<input type="button" value="Upgrade"/> <input type="button" value="Cancel"/>	

➤ **Local File:**

Type the path of the firmware in **Select File** field, or click "**Browse...**" to browse the firmware file. Press "**Upgrade**" to upload the firmware file to the CLIENT. After finishing transmitting the firmware, the system will copy the firmware file and replace the firmware in the flash.

➤ **TFTP :**

IP: This is the IP address of the TFTP server where the firmware image resides.

File Name: This is the file name of the firmware image.

Press "**Upgrade**" to activate the new password

Press "**Cancel**" to clear the entered IP address and firmware file name.

After the firmware has upgraded, the device reboots automatically.

4.4.5 Configuration File

In this Page, you can backup and restore a system configuration file by two methods, local file or TFTP server.

Configuration File

Help

Local Files

Load Settings from File:	選擇檔案 未選擇任何檔案	Upload
Save Settings to File:	Save...	
Reset Settings to Default:	Reset	<input type="checkbox"/> Include IP Settings

TFTP

IP	<input type="text"/>
File Name	ap.conf
Load/Save Settings	Load ▼ <input type="button" value="Submit"/>

➤ **Local File:**

Local setting from file: Click "**Browse...**" to select the previously saved backup configuration file.

After locating the configuration file, click "**Upload** :button

Save setting to file: Click the "**Save**" button to save the configuration file.

Reset setting to Default: Click the "**Reset**" button to reset all the configuration settings, but not the default IP address to default settings unless you select the **Include IP setting** option when you click the Reset Button.

➤ **TFTP :**

IP: This is the IP address of the TFTP server where your configuration file has been previously saved or can be saved.

File Name: This is the file name of the configuration file to be saved.


Locad/Save Settings:

Select the "**Load**" option to load the configuration from the TFTP server onto the router.

Select the "**Save**" option to save the configuration on the router to the TFTP server.

4.4.6 Certificate File

Use this page to manage the user certificate file. You can import user certificate file, select “Browse...” to select the certificate file and press “**Import**”. You can generate the file by 3rd party tool, web site or get from the IT administrator. Select the user certificate, and then use the **Delete** to remove it.



In **Wireless/Security Settings**, following is the security setting under “**WPA with Radius**” Authentication mode, the EAP type is “**TLS**”. You can see the “User Certificate file” is assigned. The CLIENT must use the same certificate file as your Radius Server under this setting.

4.4.7 Remote IP Scan

The page allow user to set remote IP Scan, it include **Cluster Name** and **IP Scan Password**. With **Remote IP Scan**, it provide higher wireless security when use Korenix View management tool.

Note: Must use Korenix View V1.6.9 or higher version

After set **Cluster Name**, Korenix View will not list JetWave device in Model filed unless user type the same Cluster name at Korenix View interface.

IP Scan

Help

Cluster Name:

Apply Cancel

IP Scan Password:

Confirm Password:

Apply Cancel

If set **Cluster Name** with **Password**, Korenix View will not list JetWave device in Model filed unless user type the same Cluster name at Korenix View interface, if user already type the same Cluster Name at Korenix View, it will list JetWave device but need to key in password if user want to modify configuration, such as Reboot, Load factory default, Change Cluster Name and Wireless panel settings.

No.	Model	Mac Address	IP Address	Netmask	Gateway	Version	Status
1	JetWave4020	00:12:77:FF:E2:01	192.168.10.42	255.255.255.0	192.168.10.99	0.9.2	
2	JetWave4020	00:12:77:11:22:33	192.168.10.10	255.255.255.0	0.0.0.0	0.9.1	

4.5 Tools

The tools provides the system tools, for example: Save the configuration, Logout and Reboot the system.

4.5.1 Save

Use this page to save configuration to flash. Every time while you finished the configuring the device, please remember to save the configuration to flash. Otherwise, the configuration will lost after reboot the system.

Save

Use this page to save configuration to flash.

Do you want to save configuration to flash?

Press **“Save to Flash”** to save the configuration to flash.

4.5.2 Logout

After finished configuring and leave, please remember to Logout the system. Without Logout the system, the login session will not timeout for couple minutes, it is a risk that other user may login your system without password checking before timeout. Another affect is that the user can NOT access at the same time if someone already login the system.

Logout

Use this page to logout.

Do you want to logout?

Use this page to logout. Press **“Yes”** to logout.

4.5.3 Reboot

Use this page to reboot the system. Press **“Yes”** to reboot system.

Reboot

Use this page to Reboot.

Do you want to reboot?

The below warning message will Appear after you reboot the system.

**This device has been reboot, you have to login again.
Please wait for 72 seconds before attempting to access the device again...**

➤ **Enable reboot time:**

Enable the reboot time and set the Time, when the Current Time ran to the value that you set, the system will reboot the device automatically. Press Apply to activate the settings.

Enable reboot time

Current Time: 14 Hr, 9 Min, 16 Sec.

Time Hr Mn



Chapter 5

Configuration – SNMP, CLI, View Utility


Chapter 5 Configuration – SNMP, CLI, View Utility

5.1 SNMP

5.1.1 What is SNMP?

Simple Network Management Protocol (SNMP) is a protocol used for exchanging management information between network devices. SNMP is a member of the TCP/IP protocol suite. This product series supports SNMP v1, v2c and V3.

Typical SNMP Architecture:



An SNMP managed network consists of two main components: Agent of the Managed Device and Manager (Network Management System, NMS).

Agent of the Managed Device: An agent is a management software module that resides in CLIENT. An agent translates the local management information (Management Information Base, MIB) from the managed device into a SNMP compatible format. In MIB, all the status and settings

of the CLIENT/Gateway has its own specific object ID (OID), the manager can read or write the value of the OID.

Manager (Network Management System, NMS): The manager is the console through the network. Network Management System (NMS) is the typical management system to manage the SNMP compatible devices. It normally provides device discovery, management, remote monitoring on network (RMON), trap server...etc.

Community:

The community is similar to the password of SNMP, while the manager wants to manage the target device, they must have the same community name. The community includes 2 privileges, Read Only and Read and Write. With Read Only privilege, you only have the ability to read the values of MIB tables. Default community string is Public. With Read and Write privilege, you have the ability to read and set the values of MIB tables. Default community string is Private.

SNMP Setup:

Please refer to the **4.6.1 Remote Setting**.

5.1.2 Management Information Base (MIB):

Before you want to manage the JetWave 2211C CLIENT through SNMP, please go to download the MIB files from Korenix web site and compile all of them to the NMS. The CLIENT supports function based MIB, the same function/parameters in all the models have the same object ID (OID). The benefit is you just need to compile the MIB file one time even you purchase different models. While you purchase our new released models in the future, the MIB file can be applied as well. Once we provide new features for the MIB, you just need one time effort to update the MIB table for all the models.


There are some MIB files which are:

- a. JETWAVE-ACL-MIB.my: This is the JetWave ACL object MIB.
- b. JETWAVE-DEVICE-MIB.my: This is the JetWave Device Management object MIB.
- c. JETWAVE-EVENT-MIB.my: This is the JetWave Event/Trap MIB.
- d. JETWAVE-ROOT-MIB.my: This is the JetWave top level object MIB.
- e. JETWAVE-SYSTEM-MIB.my: This is the JetWave System objects MIB.
- f. JETWAVE-WLAN-MIB.my: This is the JetWave Wireless LAN Setting object MIB.

(Please download the latest MIB file from Korenix web site.)

5.1.3 MIB Tree in NMS

The below figure shows the MIB tree after compiled in the NMS.



Example: wlanSetting

wlanSettingEntry:

[-] wanSettingTable
[+] wanSettingEntry
[-] vapTable
[+] vapEntry
[-] securityTable
[+] securityEntry
[-] associationListTable
[+] associationListEntry

[-] wanSettingEntry
operatemode
wirelessmode
radioEnable
ssid
hidenetworkname
frequency
datarate
beaconinterval
rtsthreshold
fraglength
dtiminterval
preamble
txpower
htprotect
channelmode
channeloffset
extchprote
shortgi
ampdu
amsdu
igmp
wmmSupport
wlanseparator
rifs
integration
maxStaNum
maxStaNumLimit
spaceinmeter
antennaNum
wdsAPMacAddress
wifiRedundancyPrimaryInterface
wifiRedundancyThreshold
roamingEnable
roamingThreshold
roamingDiff
roamingScanChannel1
roamingScanChannel2
roamingScanChannel3
autoOffloadEnable
offloadLowerSignal
offloadUpperSignal
onetimeOffloadEnable
offloadReconnectWIFI
offloadActivePath

Example of Object in wlanSettingEntry

Operatemode: (Operation Mode)

The OID: .1.3.6.1.4.1.24062.2.12.1.2.1.1.1.1.1.

Max Access: read-write

(Read and Write)

Value list: you can read


the value or set a new

value according to the

value list. This is the

same as web GUI and

CLI.



Select the OID and press the Right key of the mouse. You can see the tool set to read or write new value.


Get: Read the value of the selected OID.

GetNext: Read the value of the next OID.

GetBulk: Read the value of the next 10 OID.

Set: Set new value for the selected OID.

Property: See the MIB Node information.



5.2 Command Line Interface (CLI)

The CLIENT provides the Command Line Interface (CLI), you can access it through the Telnet or Console. The Command Line Interface (CLI) is the user interface to the CLIENT's embedded software system. You can view the system information, show the status, configure the switch and receive a response back from the system by keying in a command.

The below screen is the login screen of the CLIENT. The default username/password is admin/admin, it is the same as Web GUI. Once you modified it from other configuration interface, please type the new name/password to login.



There are some different command sets. Each command sets has its own access ability and available command lines. These command sets are:

SHOW: This is Read Only command to show the current setting and status of the CLIENT/Gateway.

SET: This is Write command to change the current setting.

LIST: This is Help command to show the usage information of the command.

Del: This is Delete command to delete the applied settings.

Exit: To exit the CLI. It is logout command.

Note: Use “**Tab**↵” key can help you find the correct command and complete the command no matter you want to Read or Write easier.

5.2.1 SHOW Command Set:

Type **Show** + “**Tab**” to see all the show command sets. The following command lines are available.

```

Telnet 192.168.10.10
Login from 192.168.10.110
User Name: admin
Password: *****
korenix112233>show
802.1Q_Vlan      Association List  firewall
ipsec           log list        mobilemanager
network         opcua           openvpn
pingwdg        radius          remote
rip            routing_table   SiteSurvey
snmp           static_route    syslog
system         time            trafficshaping
vpn-status     wlan1          wlan2
  
```

Type **show wlan1** + “**Enter**” to see all the wlan information. The console print all the information for reference.

Type **show wlan1 ra** + “**Tab**” to complete the commands, and then you can see the result.

```

korenix112233>show wlan1 ra (+Tab)
radio rate
korenix112233>show wlan1 rad (+Tab)
radio rate
korenix112233>show wlan1 radio (+ Enter)
wlan1 radio : Enabled (This is the result.)
  
```

Please check the List command set to know the usage of all commands.

5.2.2 Set Command Set:

Type **Set** + “**Tab**” to see all the write command sets. The following command lines are available.

```

Telnet 192.168.10.10
korenix112233>set
archive download-sw config
exit firewall ipsec
mobilemanager network opcua
openvpn password ping
pingwdg radius reboot
remote reset rip
SiteSurvey snmp static_route
syslog system time
trafficshaping wlan1 wlan2
write
  
```

The most Set comment lines have the same functionality as the the Web GUI configuration we

introduce in Chapter 4. Please read Chapter 4 to know all the features our CLIENT supported.

And the CLI is a different way for you to complete the setting.

Example: Set the remote configuration (Refer to the 4.6.1 – Remote Setting)

Type **set remote + “Tab↵”** to see all the remote settings.

```

korenix112233>set remote
cluster name      email alter      event warning    forcehttps
ipscan password  snmp             snmptrap
ssh               telnet
  
```

Example: SNMP Enable/Disable:

```

korenixffffff>set remote snmp
Disabled   Enabled
korenixffffff>set remote snmp Disabled
remote snmp           : Disabled
korenixffffff>set remote snmp Enabled
remote snmp           : Enabled
korenixffffff>
  
```

====SNMP Setting=====

The SNMP command lines and how to set SNMP version, community name, trap server.

korenixffffff>set snmp (+Tab)

```

getCommunity      port          setCommunity    trClientcommunity
trapdestination v3Admin          v3User          version
  
```

```

korenixffffff>set snmp version V2
snmp version      : V2
  
```

```

korenixffffff>set snmp getCommunity orwell
snmp getCommunity : orwell
  
```

```

korenixffffff>set snmp setCommunity orwell
snmp setCommunity : orwell
  
```

```


korenixffffff>set snmp trapdestination 192.168.10.95
snmp trapdestination : 192.168.10.95
  
```

```


korenixffffff>set snmp trapcommunity orwell
snmp trapcommunity : orwell
  
```

5.2.3 List Command Set:

Type **List + “Tab↵”** to see all the command usage. This is similar to the Help command.



Below command is to list the remote configuration command line and its description.



show, set and del: Which privilege the command has? [X] means Yes.

Keyword: The command you should enter in the CLI.

Description: Short description of the usage of the command.

5.2.4 Delete Command Set:

Type **del** + "**Tab**↵" to see all the delete command sets. The following command lines are available.



The log list can be delete through CLI.

korenixfffff>del log list

The configured smtp email addresses can be delete through CLI.

```
korenixfffff>del remote smtp  
email1 email2
```

The below wlan 1 settings can be delete through CLI. (JetWave 2211C 1st Radio)

```
korenixfffff>del wlan1  
acl eapkey wpa
```

5.3 Korenix View Utility

The Korenix View Utility (Rename from the JetView) provides you convenient tool to scan the network and configure the CLIENT. Please connect your PC to JetWave 2211C Ethernet port and start below steps to scan and configure.


5.3.1 Device Discovery:

Step 1: Open the Korenix View Utility. (Must later than V1.6.11)


Step 2: Select the correct NIC (Network Interface Card) from the NIC list or remains the “All Interfaces”.

Step 3: Click “**Discovery**”, and then the Nodes and its IP address can be found and listed in Node list.

➤ Figure: The main screen of the Korenix View Utility




➤ Figure: The Device Discovery Screen, please wait couple seconds.







5.3.2 Basic Tools Shortcut:

After you scan the network, select the CLIENT and click Right key of mouse, you can see some tools.


- a. You can modify the IP address/Netmask directly on the field and then click **“Change IP”** to change the IP settings.
- b. Select multiple devices and click **“Auto-Assign IP”**, the popup screen will ask you type the IP Address range. You can assign new IP address for the selected devices.




- c. You can enable DHCP client by **“DHCP Client Enable”**.
- d. You can upgrade firmware for single or multiple units by **“Firmware Upgrade”**. A popup screen will ask you select the target firmware file you'd like to upgrade.
- e. You can Backup/Restore the configuration file by **“Configuration File -> Backup/Restore”**. A popup screen will ask you select target configuration/target folder you'd like to backup or restore.



- f. Click **“Open Web GUI”** to access the web management interface.
- g. You can reboot the device by **“Reboot Device”**. A popup screen will ask you confirm again.




- h. You can restore to default configuration by **“Load Factory Default”**. A popup screen will ask you confirm again.



Note: You can also find these commands in the upper menu of the Korenix View Utility.

5.3.3 Wireless Panel

Korenix View Utility provides Wireless panel to configure some **Basic Setting** and **Security setting** for Wireless LAN Interfaces. You can use the tool to configure settings for single device or a group of devices. Select the target device/devices for further configuration.



Basic Setting

JetWave4020 00:12:77:11:22:33

WLAN 1 | WLAN 2

Basic Setting | Security Setting

Disable WLAN Interface

Operation Mode: AP Mode

SSID: JetWave_1

Broadcast SSID: Enabled Disabled

802.11 Mode: 802.11G/N

Frequency/Channel: 2437MHz (6)

Channel Mode: 20 MHz

Max. Output Power: Full

Refresh

Apply

Security Setting

JetWave4020 00:12:77:11:22:33

WLAN 1 | WLAN 2

Basic Setting | Security Setting

Profile: Profile1

Network Authentication: Open-System

Data Encryption: none

Default Tx Key: key 1

Encryption Key 1:

Encryption Key 2:

Encryption Key 3:

Encryption Key 4:

Refresh

Apply

Basic Setting

The Basic Setting panel allows you Disable WLAN Interface, configure the Operating Mode, SSID, Broadcast SSID, Enable/Disable, 802.11 Mode, Frequency/Channel, Channel Mode and Max. output power.

Press “**Apply**” to activate the new settings.

Security Setting

The Security Setting panel allows you to configure the Network Authentication type and the encryption keys for the CLIENT profile.

Press “**Apply**” to activate the new settings.



Note:

Must click “**Refresh**” to load the current configuration of the selected CLIENT



Chapter 6 Troubleshooting

Chapter 6 Troubleshooting

This Chapter provides troubleshooting procedures for basic problems with the JetWave 2211C. For warranty assistance, contact your service provider or distributor for the process.

6.1 General Question

6.1.1 How to know the MAC address of the CLIENT?

MAC Address distinguishes itself by the unique identity among network devices. There are two ways available to know it.

Each device has a label posted on the side of the CLIENT. There are MAC addresses for Ethernet and Radio interfaces. On the Web-based management interface, you can view the MAC Address from “**Status**” -> “**Information**”. You can also see this in CLI or SNMP OID.

6.1.2 What if I would like to reset the unit to default settings?

You can reset the unit to default setting in Web GUI. You can reserve the IP address setting.

6.1.3 Why can not access the Web-based management interface?

Please check the followings:

- Check whether the IP address of PC is correct (In the same network segment as the unit)
- Login the unit via other browsers such as Firefox, Google Chrome.
- Use Korenix View Utility to scan the CLIENT and check/modify the IP address.
- If everything is correct, but, you still can't access the web GUI, we suggest you connect the console cable to do further checking. Please refer to the pin assignment in hardware installation Chapter.
- Check whether the power supply is OK; Try to power on the unit again. If the web GUI can't be accessed issue occurred again, please contact our technical service engineer. We may ask you connect console cable and provide us more information.

6.2 Wireless

6.2.1 What if the wireless connection is not stable after associating with an CLIENT under wireless client mode?

- In addition, you can start “**Site Survey**” to check the signal strength. If it is weak or unstable (The smaller the number is, the weaker the signal strength is.), please join other available CLIENT for better connection.
- If you install the directional antenna for point to point/multi-point connection, adjust the antenna and tune the signal strength/performance by Antenna Alignment Tool again. After antenna alignment, the data rate test can help you check the current performance.
- In Wireless client mode, type the connected CLIENT’ MAC address to fix the CLIENT for your client. It avoid your wireless client not to connect other CLIENT.

6.2.2 What if the wireless connection performance is not good, how to improve it?

- Once the signal strength RSSI is always under **-65dbm** in long distance transmission, it is suggest you to change antenna’s direction or replace antenna with higher gain.
- If the distance between the wireless client and target CLIENT is short, but, the antenna gain is very high. Reduce the RF power is also an option.

6.3 Appendix

6.3.1 ASCII

WEP can be configured with a 64-bit or 128-bit Shared Key (hexadecimal number or ACSII). As defined, hexadecimal number is represented by 0-9, A-F or a-f; ACSII is represented by 0-9, A-F, a-f or punctuation. Each one consists of two-digit hexadecimal.

ASCII Table

ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent
!	21	9	39	Q	51	i	69
"	22	:	3A	R	52	j	6A
#	23	;	3B	S	53	k	6B
\$	24	<	3C	T	54	l	6C
%	25	=	3D	U	55	m	6D
&	26	>	3E	V	56	n	6E
'	27	?	3F	W	57	o	6F
(28	@	40	X	58	p	70
)	29	A	41	Y	59	q	71
*	2A	B	42	Z	5A	r	72
+	2B	C	43	[5B	s	73
,	2C	D	44	\	5C	t	74
-	2D	E	45]	5D	u	75
.	2E	F	46	^	5E	v	76
/	2F	G	47	_	5F	w	77
0	30	H	48	`	60	x	78
1	31	I	49	a	61	y	79
2	32	J	4A	b	62	z	7A
3	33	K	4B	c	63	{	7B
4	34	L	4C	d	64		7C
5	35	M	4D	e	65	}	7D
6	36	N	4E	f	66	~	7E
7	37	O	4F	g	67		
8	38	P	50	h	68		

Revision History

Version	Description	Date	Editor
V1.0	1 st release for JetWave 2211C	Oct. 2018	Shelly Tsai